

Adaptive Threshold Based Sampling

Cyclone V: 5CSXFC6D6F31C6 (DE10-Standard FPGA Board)

Type	Name	Func	Description
Button	KEY0	reset	reset
Button	KEY1	trigger_start_sampling	manual sampling trigger (optional, instead of AWG trigger)
Switch	SW0	trigger_start_mode	'1' Start sampling on trigger - '0' Start sampling directly
Switch	SW1	adaptive_mode	'1' ATBS - '0' TBS
Switch	SW2	control_mode	'1' UART - '0' Switches
Switch	SW3	signal_select_in	'1' BNC - '0' ECG
Switch	SW4	enable	'1' Enable - '0' Disable
Switch	SW5	select_tbs_delta_steps	'1' "virtual" DAC resolution - '0' full DAC resolution
Switch	SW6	select_comparator_type	'1' Modeling DT comparator - '0' Modeling CT comparator
UART	-	trigger_start_mode	'1' Start sampling on trigger - '0' Start sampling directly
UART	-	adaptive_mode	'3' ATBS - '2' TBS
UART	-	signal_select_in	'5' BNC - '4' ECG
UART	-	enable	'7' Enable - '6' Disable
UART	-	select_tbs_delta_steps	'9' "virtual" DAC resolution - '8' full DAC resolution
UART	-	update config.	'U'
UART	-	start sampling	'S' (enter 2x)
UART	-	reset	'R'
UART	-	analog trigger settings	'T' and 'a' to 'f'
UART	-	SC NOC generator settings	'C' and 'a' to 'c'
UART	-	UART baudrate	'B' and 'a' to 'd'

Type	Name	Func	Description
UART	-	TBS virtual delta steps	'V' and 'a' to 'e'
UART	-	ATBS win_length / time_win	'W' and 'a' to 'd'
UART	-	ATBS deltasteps_max	'D' and 'a' to 'e'
LED	LEDR0	idle	'1'... Lights up, if Main FSM is in idle state!
LED	LEDR1	overflow	'1'... Lights up, if FIFO is full!
LED	LEDR2	underflow	'1'... Lights up, if FIFO is empty!
LED	LEDR3	ecg	'1'... Lights up, if ECG electrodes are connected!